

# **QWISE-FM-SBJSGC-2019-SSDL**

## **Company Standard**

**Hunan WISE New Material Technology Co., Ltd.**

---

### **Powder sub-factory**

### **Powder product**

### **production process equipment**

### **safety technical regulations**

**Experimental electric furnace safety technical regulations**

Approved by : Zhaohui LIU                      Prepared by: Liyun Yun    Xing Wang

Checked by Technical Dept : Yizhong Zhang   and   Yongshen Gong

Checked by Sub-Factory: Zhengchen Xu   and   Zhengdao Xiao

August 1, 2019   Release

August 1, 2019   Effective

**Hunan WISE New Material Technology Co., Ltd. Release**

# **QWISE-FM-SBJSGC-2019-SSDL**

## **Company Standard**

**Hunan WISE New Material Technology Co., Ltd.**

---

### **Powder sub-factory**

#### **production process equipment safety technical regulations**

##### **Experimental electric furnace safety technical regulations**

- 1、Wear overalls,work shoes,gloves,and dust masks before operation.
- 2、Before heating,the air should be turned on to confirm the position of the scale that meets the temperature requirements.The circuit system and the vacuum system can be operated without leakage.
- 3、During the drying process,the temperature change in the drying oven should be checked frequently,and the degree of vacuum should be adjusted according to the temperature change.
- 4、The vacuum pump is refueled once every other time according to the frequency of use of the experimental electric furnace.
- 5、After using,disconnect the power supply of each system in time to keep the equipment and the site environment clean and tidy.

Approved by : Zhaohui LIU

Prepared by: Liyun Yun Xing Wang

Checked by Technical Dept : Yizhong Zhang and Yongshen Gong

Checked by Sub-Factory: Zhengchen Xu and Zhengdao Xiao

August 1, 2019 Release

August 1, 2019 Effective

**Hunan WISE New Material Technology Co., Ltd. Release**